

## Prepare the wall

The wall surface should be clean, dry, structurally sound and free of mildew, grease, or other stains, and free of irregularities in order to achieve the best hanging performance and complete removal when redecorating.

**New Construction:** Use a white wall covering primer to conceal joints.

Roman: PRO-977 ULTRA-PRIME® Premium Pigmented Primer or similar is recommended.

**Existing Construction:** Thoroughly clean surface of all dirt, grease, and anything that might adversely effect proper installation. Properly prime surface with suitable product.

For painted drywall, Roman: PRO-909 VINYL PREP® Clear Wallpaper Primer or similar is recommended. When hanging on other surfaces use proper primer for the surface to be applied..

## Apply the wallpaper

For new construction drywall and existing drywall installations use strippable wallcovering adhesive or similar

Apply paste to wall with roller. For best results use a soft bristle brush working from the center of the panel out and smooth product on the wall. Use plastic strip or tape at seam to allow double cutting for a butt to butt installation. Clean any paste from the surface with a soft, damp sponge. Apply paste for next panel. Line up panels at eye level and smooth from center out. Using proper primer and ample paste will allow the paper to slide into alignment with previous panel.

Move around the room from left to right. Pick up your second panel of wallpaper and apply it so that its left side overlaps the right side of the previous panel by approximately 3/4 inch, carefully matching the repeat. The paper may be completed this way, or you may wish to perform a double cut for a flush seam.

